

Installation and service instructions

for contractors

VIESSMANN

Vitodens 100

6.5 to 35.0 kW

Wall mounted gas condensing boiler

Natural gas version

For applicability, see the last page



VITODENS 100



Safety instructions



Please follow these safety instructions closely to prevent accidents and material losses.

Safety instructions explained



Danger

This symbol warns against the risk of injury.

Note

Details identified by the word "Note" contain additional information.



Please note

This symbol warns against the risk of material losses and environmental pollution.

Target group

These instructions are exclusively intended for qualified contractors.

- Work on gas installations may only be carried out by a registered gas fitter.
- Work on electrical equipment may only be carried out by a qualified electrician.
- The system must be commissioned by the system installer or a qualified person authorised by the installer.

Regulations to be observed

- National installation regulations
- Statutory regulations for the prevention of accidents
- Statutory regulations for environmental protection
- Codes of practice of the relevant trade associations
- Relevant country-specific safety regulations

Safety instructions (cont.)

Safety instructions for working on the system

Working on the system

- Where gas is used as the fuel, close the main gas shut-off valve and safeguard it against unintentional reopening.
- Isolate the system from the power supply, e.g. by removing the separate fuse or by means of a mains isolator, and check that it is no longer live.
- Safeguard the system against reconnection.
- Wear suitable personal protective equipment when carrying out any work.



Danger

Hot surfaces and fluids can lead to burns or scalding.

- Before maintenance and service work, switch OFF the appliance and let it cool down.
- Never touch hot surfaces on the boiler, burner, flue system or pipework.



Please note

Electronic assemblies can be damaged by electrostatic discharge.
Prior to commencing work, touch earthed objects such as heating or water pipes to discharge static loads.

Repair work



Please note

Repairing components that fulfil a safety function can compromise the safe operation of the system.

Replace faulty components only with genuine Viessmann spare parts.

Auxiliary components, spare and wearing parts



Please note

Spare and wearing parts that have not been tested together with the system can compromise its function. Installing non-authorised components and making non-approved modifications or conversions can compromise safety and may invalidate our warranty.

For replacements, use only original spare parts supplied or approved by Viessmann.

Safety instructions (cont.)

Safety instructions for operating the system

If you smell gas



Danger

Escaping gas can lead to explosions which may result in serious injury.

- Do not smoke. Prevent naked flames and sparks. Never switch lights or electrical appliances on or off.
- Close the gas shut-off valve.
- Open windows and doors.
- Evacuate any people from the danger zone.
- Notify your gas or electricity supply utility from outside the building.
- Have the power supply to the building shut off from a safe place (outside the building).

If you smell flue gas



Danger

Flue gas can lead to life threatening poisoning.

- Shut down the heating system.
- Ventilate the installation site.
- Close doors to living spaces to prevent flue gases from spreading.

What to do if water escapes from the appliance



Danger

If water escapes from the appliance there is a risk of electrocution.

Switch OFF the heating system at the external isolator (e.g. fuse box, domestic distribution board).



Danger

If water escapes from the appliance there is a risk of scalding. Never touch hot heating water.

Condensate



Danger

Contact with condensate can be harmful to health.

Never let condensate touch your skin or eyes and do not swallow it.

Flue systems and combustion air

Ensure that flue systems are clear and cannot be sealed, for instance due to accumulation of condensate or other external causes.

Ensure an adequate supply of combustion air.

Inform system users that subsequent modifications to the building characteristics are not permissible (e.g. cable/ pipework routing, cladding or partitions).

Safety instructions (cont.)**Danger**

Leaking or blocked flue systems, or an inadequate supply of combustion air can cause life threatening poisoning from carbon monoxide in the flue gas. Ensure the flue system is in good working order. Vents for supplying combustion air must be non-sealable.

**Danger**

The simultaneous operation of the boiler and appliances that extract air to the outside can result in life threatening poisoning due to a reverse flow of flue gas. Fit an interlock circuit or take suitable steps to ensure an adequate supply of combustion air.

Extractors

Operating appliances that exhaust air to the outside (extractor hoods, extractors, air conditioning units, etc.) can create negative pressure. If the boiler is operated at the same time, this can lead to a reverse flow of flue gas.

Index

Service instructions

Warning notices

Warning notices according to GB25034-2010.....	8
Frost protection.....	9
Intended use.....	9
Notes on siting, installation and operation.....	10

Information

Symbols.....	11
--------------	----

Installation instructions

Preparing for installation.....	12
---------------------------------	----

Installation sequence

Mounting the boiler and making connections.....	15
Opening the control unit enclosure.....	25
Electrical connections.....	26

Service instructions

Commissioning, inspection, maintenance

Steps - commissioning, inspection and maintenance.....	33
Further details regarding the individual steps.....	35

Parameter

Main parameter level.....	55
Parameter level 1.....	57
Parameter level 2.....	59

Diagnostics

Function sequence and possible faults.....	61
Overview of checks.....	62
Status checks.....	62
Meter checks.....	64

Troubleshooting

Fault display.....	66
Repairs.....	70

Control unit

Weather-compensated operation.....	81
------------------------------------	----

Index (cont.)**Designs**

Connection and wiring diagram.....	83
------------------------------------	----

Parts lists

Ordering parts.....	85
Overview of assemblies.....	86
Casing assembly.....	87
Heat cell assembly.....	89
Burner assembly.....	91
Hydraulic assembly.....	93
Hydraulic assembly, system boiler.....	95
Hydraulic assembly, combi boiler.....	97
Control unit assembly.....	99
Miscellaneous assembly.....	101

Specification	102
----------------------------	-----

Certificates

Manufacturer's declaration for Vitodens 100 CC.....	109
---	-----

Keyword index	110
----------------------------	-----

Warning notices according to GB25034-2010

Warning against incorrect use:

- A faulty installation can lead to injury and material losses.
- The appliance must be installed in accordance with the instructions and applicable legal regulations.
- Only engineers or persons approved by the manufacturer may repair the appliance or replace parts of it.
- To ensure the safety of the product, only original accessories can be used.
- The original flue pipe must be used. Flue pipes of any other type must not be used. The concentric flue pipe must not be replaced by a single flue pipe.
- If it is necessary to replace the gas governor or controls, please contact the manufacturer.
- Do not purchase any equipment modified by dealers; only purchase the manufacturer's original product. This is the only way to ensure the safety of the appliance.
- When installing the appliance, install a shut-off valve in the gas supply line.
- Do not install the appliance near electrical equipment with a strong electromagnetic field, such as an electromagnetic oven or microwave.
- Do not remove any sealed parts from the appliance.
- Do not use caustic cleaning agents to clean the appliance.
- The appliance must not be installed in bedrooms, living rooms or bathrooms.
- Ensure that the appliance is not operated by children or other persons who do not use it. Ensure that children do not play with the appliance.
- The overheating safety valve and the hot water drain valve may only be operated by specialists or competent persons.
- Do not install the appliance in closed rooms.
- After maintenance or inspection of the appliance, the results must be noted on the appliance by the maintenance or inspection engineer.
- The power supply to the room must be earthed.
The switch connected to the appliance must not be located in a room with a bath or shower.
The closure and the closure seal must be checked.
- Explain the frost protection measures for the appliance to the user. The user can add antifreeze to the heating water circuit if the appliance is not operated for a long period in winter. Otherwise the appliance or pipes can be damaged by freezing.

Frost protection



Please note

Frost protection is only guaranteed with a reliable power supply, gas supply and sufficient heating water content.

Following installation or repairs, switch ON the power supply (MCB/fuse, mains isolator) and the control unit ON/OFF switch. Open the gas shut-off valve to ensure frost protection.

Intended use

The appliance is only intended to be installed and operated in sealed unvented heating systems that comply with EN 12828 and CECS 215, with due attention paid to the associated installation, service and operating instructions. It is only designed for heating up heating water that is of potable water quality.

Intended use presupposes that a fixed installation in conjunction with permissible, system-specific components has been carried out.

Commercial or industrial usage for a purpose other than heating the building or DHW shall be deemed inappropriate.










Any usage beyond this must be approved by the manufacturer in each individual case.

Incorrect usage or operation of the appliance (e.g. the appliance being opened by the system user) is prohibited and will result in an exclusion of liability. Incorrect usage also occurs if the components in the heating system are modified from their intended use (e.g. if the flue gas and ventilation air paths are sealed).







Notes on siting, installation and operation

- Installation, maintenance and service must be carried out by an authorised contractor.
- The boiler installation must meet the following local requirements:
 - Safety conditions for the gas supply
 - Guidelines for water supply and waste water disposal
 - Construction guidelines
- The surface temperatures of the boiler and flue system do not necessitate any safety clearances for fire protection.
- After installation, the heating contractor should mark the position of the flue system and instruct the system user about operation and the safety regulations.
- The appliance power cable and leads may only be replaced by an authorised contractor or a specialist authorised by the contractor.
- To ensure trouble-free and efficient operation, the heating system should be checked and serviced once a year by an authorised contractor.

Symbols

Sym- bol	Meaning
	Reference to another document containing further information
	Step in a diagram: The numbers correspond to the order in which the steps are carried out.
	Warning of material losses and environmental pollution
	Live electrical area
	Pay particular attention.
	<ul style="list-style-type: none"> ■ Component must audibly click into place. or ■ Acoustic signal
	<ul style="list-style-type: none"> ■ Fit new component. or ■ Using a tool: Clean the surface.
	Dispose of component correctly.
	Dispose of component at a suitable collection point. Do not dispose of component in domestic waste.

The sequences of steps for commissioning, inspection and maintenance are summarised in the section "Commissioning, inspection and maintenance" and are identified as follows:

Sym- bol	Meaning
	Steps required during commissioning
	Not required during commissioning
	Steps required during inspection
	Not required during inspection
	Steps required during maintenance
	Not required during maintenance

Preparing for installation

Product information

Vitodens 100

Preset for operation with natural gas. The Vitodens 100 may only be delivered to countries listed on the type plate. For deliveries to other countries, approved contractors must arrange individual approval on their own initiative and in accordance with the law of the country in question.

Product description

The Vitodens 100 is supplied as a gas condensing boiler for connection to a DHW cylinder, or as a gas condensing combi boiler with an integral instantaneous water heater for DHW heating.


The boiler is equipped with a hydraulic system with the following components:

- Circulation pump
- 3-way diverter valve
- Safety valve
- Diaphragm expansion vessel
- Plate heat exchanger (gas condensing combi boiler)
- Connections for heating water flow and return
- Connections for cylinder flow and return (gas condensing system boiler)
- Connections for cold water and DHW (gas condensing combi boiler)

In the delivered condition, the Vitodens 100 CC is set up for operation with a constant boiler water temperature. By connecting an outside temperature sensor, available as an accessory, the boiler can be operated in weather-compensated mode. In this case, a room temperature controller should always be connected as well. This prevents heat being generated unnecessarily, for example at night, due to the lower outside temperatures. If a Viessmann DHW cylinder is connected, the request for cylinder heating is made via a cylinder temperature sensor. The cylinder temperature sensor is connected to the control unit.

Preparing for installation (cont.)

Dimensions and connections



- (A) Heating flow G $\frac{3}{4}$
- (B) Gas condensing system boiler:
Cylinder flow G $\frac{3}{4}$
Gas condensing combi boiler:
DHW G $\frac{1}{2}$
- (C) Gas connection G $\frac{3}{4}$
- (D) Gas condensing system boiler:
Cylinder return G $\frac{3}{4}$
Gas condensing combi boiler:
Cold water G $\frac{1}{2}$
- (E) Heating return G $\frac{3}{4}$
- (F) Condensate drain/safety valve
drain: Plastic hose \varnothing 22 mm

Preparing for installation (cont.)

Preparing for boiler installation

Preparing the connections




Please note

To prevent appliance damage, connect all pipework free of load and torque stress.

1. Prepare the water connections.
Flush the heating system.
2. Prepare the gas connection.
3. Prepare the electrical connections.
 - The appliance is delivered fitted with a 1.3 m long (outside the boiler) power cable NYM-J 3 x 1.5 mm² with plug.
 - Cables for accessories: NYM-O 2-core min. 0.5 mm² or 2-core LV lead.

Mounting the boiler and making connections

Fitting the wall mounting bracket




(A) Vitodens installation template

Mounting the boiler and making connections (cont.)

1. Position the supplied installation template on the wall.
2. Mark out the rawl plug holes.
3. Drill \varnothing 10 mm holes and insert the rawl plugs supplied.
4. Fit the wall mounting bracket with the screws supplied.

Mounting the boiler and making connections (cont.)


Removing the front panel and mounting the boiler



1. Undo the screws on the underside of the boiler; do not remove them completely.
2. Remove front panel.
3. Hook the boiler into the wall mounting bracket.

Mounting the boiler and making connections (cont.)

Fitting connections on water side



- Ⓐ Heating flow
- Ⓑ Gas condensing system boiler:
Cylinder flow
Gas condensing combi boiler:
DHW
- Ⓒ Gas connection
- Ⓓ Gas condensing system boiler:
Cylinder return
Gas condensing combi boiler:
Cold water
- Ⓔ Heating return


Fitting the connection set




Connection set installation
instructions

Mounting the boiler and making connections (cont.)

Connection set for gas condensing boiler (accessories)




Connection set for gas condensing combi boiler (accessories)



Gas connection

- Gas supply pressure: 15 - 30 mbar (1.5 - 3.0 kPa)
- Set value: 20 mbar (2.0 kPa)



1. Connect the gas shut-off valve (on-site) to adaptor (A).



Mounting the boiler and making connections (cont.)

2. Carry out a tightness test.

Note

Only use suitable and approved leak detection agents (EN 14291) and devices for the tightness test. Leak detection agents with unsuitable constituents (e.g. nitrides, sulphides) can cause material damage. Remove residues of the leak detection agent after testing.




Please note

Excessive test pressure will damage the boiler and the gas train.
Max. test pressure 150 mbar (15 kPa). If a higher pressure is required for tightness tests, disconnect the boiler and the gas train from the main supply pipe. Undo the fitting.

3. Purge the gas line.

Mounting the boiler and making connections (cont.)

Connecting the safety valve and condensate drain



Connect condensate pipe (A) to the public sewage system with a constant fall and a pipe vent.


Treating and draining off condensate:

- A neutralising system is available as an accessory on request.
- Do not drain condensate that has not been neutralised through pipes made from steel or other metallic materials.
- Do not close off the condensate pipe or change its position.
- Observe local rules and waste water regulations for draining off condensate.

Note

Fill the trap with water before commissioning.

Filling the trap with water



Pour at least 0.3 l of water into the flue gas connection.




Please note

During commissioning, flue gas may escape from the condensate drain.

Always fill the trap with water before commissioning.

Mounting the boiler and making connections (cont.)

Balanced flue connection



General installation information

Note

- The boiler may only be operated with a balanced flue system of $\varnothing 60/100$ mm.
- The balanced flue system must be at least 1 m long, incl. 90° bend.



Please note

If a single flue pipe is used, the boiler has no protection against splashing water. Only connect a concentric balanced flue pipe or balanced flue bend of $\varnothing 60/100$ mm to the boiler.

Design

Prior to installation, check that the maximum possible pipe length of 5 m will not be exceeded.

Flue gas temperature protection

The flue pipes are approved for flue gas temperatures up to 120 °C.

The shutdown threshold of the integral flue gas temperature sensor is 110 °C maximum, so that the maximum permissible flue gas temperature cannot be exceeded. This shutdown threshold cannot be changed.

Installation information


- Keep flue gas routes short and with the fewest number of bends possible.
- Check whether the gaskets in all female connections are correctly seated.
- Use only the special gaskets supplied with the boiler.
- Plug-in female connections in the flue must always point in the flow direction.
- Only use the components supplied with the PP's flue system.
- Push the pipes into each other with a slight twisting motion.
- Balanced flue pipes can be trimmed in their assembled state.

Certification of the balanced flue system

The balanced flue system is CE designated and approved (see Vitodens flue systems technical guide).


Mounting the boiler and making connections (cont.)

Installing a flue system for external wall connection




1. Create a wall opening with a min. diameter of 105 mm.
2. Push external wall connection (A) with wall bezel (B) into the wall opening.
3. Secure wall bezel (C) internally.
4. If the external wall connection terminates near public roads up to a height of 2 m above ground level, fit a protective grille.

Mounting the boiler and making connections (cont.)



5. Connect the balanced flue connection pipe from the inside and route with a fall of min. 3° (approx. 50 mm/m) towards the boiler in order to prevent condensate escaping to the outside.

Opening the control unit enclosure




Please note

Electronic assemblies can be damaged by electrostatic discharge.

Prior to commencing any work, touch earthed objects such as heating or water pipes to discharge static loads.

Electrical connections



- CN3 Ext. extension AUX 900101 (A) (accessories)
- X1 Cylinder temperature sensor (E) (only for gas system boilers)
- X2 Power supply (F) (230 V, 50 Hz)
A power cable with plug is connected in the delivered condition.
- X3 Gas pressure switch (D) (accessories)
- X7 Connecting cable (accessories) with
(B) Room/outside temperature sensor (accessories part no. 7554227)
or
(C) OpenTherm room temperature controller (accessories, e.g. Vitotrol 100 OT and Vitotrol 100 UTDB)

- X11 WLAN module (internet inside)
- X13 Power supply WLAN module (internet inside)


Electrical connections (cont.)



Information on connecting accessories

When connecting accessories observe the separate installation instructions provided with them.

Cable entry



- (A) Room temperature controller connecting cable
- (B) LV leads (sensor leads)

Outside temperature sensor or room temperature sensor (accessories)

1. Fit the temperature sensor.

Outside temperature sensor installation location:

- North or north-westerly wall, 2 to 2.5 m above ground level. In multi storey buildings, in the upper half of the second floor
- Not above windows, doors or vents
- Not immediately below balconies or gutters
- Never render over
- Connection:
2-core lead for low voltage, length up to 35 m


2. Plug the connecting cable supplied into slot "X7".
3. Connect the temperature sensor to terminals 3 and 4 (see page 26).
4. Set the function of the sensor at the control unit during commissioning (see page 41).

Note

For function description see page 81.

Electrical connections (cont.)

Connection Vitotrol 100, type UTDB



Note

Observe parameter "P07", see page 58.


Recommended connecting cable

- 2-core cable for low voltage

- (A) Vitotrol 100, type UTDB
(B) Terminals on the control unit

Electrical connections (cont.)

Connection Vitotrol 100, type UTDB-RF



Note

Observe parameter "P08", see page 59.


Recommended connecting cable

- 2-core cable for low voltage

- (A) Vitotrol 100, type UTDB-RF
(B) Terminals on the control unit

Electrical connections (cont.)

Connection OpenTherm accessories



Note

Observe parameter "P07", see page 58.

Recommended connecting cable

- 2-core cable for low voltage

- (A) OpenTherm accessories
- (B) Terminals on the control unit

Connecting system to equipotential bonding of the building




Danger

The absence of system component earthing can lead to serious injury from electric current if an electrical fault occurs.

The appliance and pipework (especially the gas line) must be connected to the equipotential bonding of the building.

Electrical connections (cont.)



- (A) Boiler
- (B) Domestic distribution box
- (C) Gas line

- (D) Earthing clip
- (E) Equipotential bonding bar
- (F) Metal pipes

Cross-section of earth cables and earth conductors: 2.5 mm² to 6 mm²

Electrical connections (cont.)

Power supply

Regulations and directives



Danger

Incorrectly executed electrical installations can result in injuries from electrical current and damage to the appliance.

Connect the power supply and implement all safety measures (e.g. RCD circuit) in accordance with the following regulations:

- National regulations:
 - GB13955-2005
 - GB50096-2011
 - GB50575-2010
- Connection requirements specified by your local power supply utility

Power supply to boiler:

- Protect with a fuse/MCB of up to 16 A.
- Install residual current device (RCD).
- Fit a secure earth connection.
- Install in a securely mounted junction box.


Routing cables/leads and closing the control unit enclosure



Please note

Connecting cables/leads will be damaged if they touch hot components.

When routing and securing cables/leads on site, ensure that the maximum permissible temperature for these is not exceeded.



Steps - commissioning, inspection and maintenance

For further information regarding the individual steps, see the page indicated

	Commissioning steps	Inspection steps	Maintenance steps	Page
•	•	•	•	1. Filling the heating system..... 35
•	•	•	•	2. Setting the time and date..... 40
•	•	•	•	3. Making the settings for operation with outside temperature sensor or room temperature sensor..... 41
•	•	•	•	4. Activating/deactivating WLAN module..... 41
•	•	•	•	5. Making the settings for operation with external extension..... 42
•	•	•	•	6. Switching off DHW heating..... 43
•	•	•	•	7. Checking the static pressure and supply pressure.... 44
•	•	•	•	8. Checking the CO ₂ content..... 45
•	•	•	•	9. Limiting the maximum heating output..... 47
•	•	•	•	10. Removing the burner..... 47
•	•	•	•	11. Checking the burner gasket and burner gauze assembly..... 48
•	•	•	•	12. Checking and adjusting the electrode..... 49
•	•	•	•	13. Cleaning the heat exchanger..... 50
•	•	•	•	14. Condensate drain check and trap cleaning..... 50
•	•	•	•	15. Installing the burner..... 51
•	•	•	•	16. Checking the diaphragm expansion vessel and system pressure..... 52
•	•	•	•	17. Checking all connections on the heating water and DHW sides for leaks
•	•	•	•	18. Checking the flue system for unrestricted flow and leaks
•	•	•	•	19. Checking the electrical connections for firm seating
•	•	•	•	20. Checking gas equipment for leaks at operating pressure..... 53

Steps - commissioning, inspection and... (cont.)

	Commissioning steps	
	Inspection steps	
	Maintenance steps	Page
•	21. Mounting the front panel.....	53
•	22. Marking the position of the flue system	
•	23. Instructing the system user.....	54

Further details regarding the individual steps

Filling the heating system

Fill water



Please note

Unsuitable fill water increases the level of deposits and corrosion and may lead to boiler damage.

- Flush the heating system thoroughly before filling.
 - Only use water of potable water quality. The total concentration of calcium Ca_{2+} and magnesium Mg_{2+} in the fill water must not exceed **450 mg/l**.
 - In areas with water hardness > 450 mg/l a water softening system must be installed.
 - Small softening systems for heating water are available from Viessmann.
 - The pH value of the fill water should be between 6.5 and 8.5.
 - Special antifreeze suitable for heating systems can be added to the fill water. The antifreeze manufacturer must verify its suitability.
 - When using a means of water treatment, always use products from the following manufacturers:
 - Fernox (www.fernox.com)
 - Scalemaster (www.scalemaster.co.uk)
 - Calmag (www.calmagltd.com)
 - Sentinel (www.sentinel-solutions.net)
1. Check the pre-charge pressure of the diaphragm expansion vessel (see page 52).
 2. Close the gas shut-off valve.

Further details regarding the individual steps (cont.)


3. Turn ON the system ON/OFF switch on the control unit.

If the system pressure is too low, the pressure will be shown on the main display after a short time:


- Display **"06"** flashing: System pressure < 0.03 MPa – top up with water
- Pressure display **"0.03"** - **"0.08 MPa"** flashing: Top up with water

4. Display of current system pressure during the filling process:


- System pressure < 0.08 MPa:
System pressure between 0.03 and 0.08 MPa: Pressure is automatically shown on the display.
System pressure > 0.1 MPa:
Pressure is displayed for a further minute. (Pressing **OK** prematurely deactivates the pressure display.)
- System pressure > 0.08 MPa:
Use ▲/▼ to select **"IF00"** to activate the pressure display.



Further details regarding the individual steps (cont.)



5. Open shut-off valves (A) and (B) (if fitted).



6. Fill the heating system:
 - Gas condensing system boiler:
Via fill valve (C) in the connection set (if supplied) or via on-site fill valve.
 - Gas condensing combi boiler:
Via fill valve (C) in the connection set (if supplied) or alternatively via fill valve (D) on the underside of the boiler.

**Minimum system pressure
> 0.08 MPa.**


Enter the measured value in the enclosed "Guarantee card".

Further details regarding the individual steps (cont.)

7. **!** **Please note**
If the system pressure falls below 0.08 MPa, the circulation pump will suffer damage.
In the event of a pressure drop immediately top up the water.
Ensure a **minimum system pressure of > 0.08 MPa** during the filling and venting process.
8. For activating the filling and venting function, see next chapter.
9. After the system has been fully charged and vented, turn OFF the ON/OFF switch at the control unit. The function will also terminate automatically after 30 min.
10. Close the fill valve.


Further details regarding the individual steps (cont.)

Venting the boiler by flushing




1. Connect the drain hose fitted at shut-off valve (A) to a drain connection.
2. Close shut-off valve (B).
3. Open valves (A) and (C) and flush at mains pressure until no sound of escaping air can be heard.
4. First close valve (A) and after that valve (C).
5. Adjust the operating pressure ≥ 0.8 bar (80 kPa) with valve (C).
6. Open shut-off valve (B).
7. Disconnect drain hose and keep safe.


Activating the filling and venting function

1. Hold down **MODE** and **▲** simultaneously for approx. 5 s.
 - "Set" is displayed.
 -  flashes.
 - "PL:1" is shown on the additional display.
2. Press **MODE**.
3. Use **▲/▼** to select "**P02**".
4. **OK** to confirm
5. Use **▲** to select "**On**".
6. **OK** to confirm
7. Press **MODE** to exit the menu.

Further details regarding the individual steps (cont.)

Filling and venting function is active:


- "Air",  and the remaining time in minutes for the process are displayed.



- The 3-way valve is switched to its central position. This ensures the entire heating system is filled.
- The burner is switched off.

- The circulation pump runs continuously.

Setting the time and date




1. Hold down **MODE** and ▼ simultaneously for approx. 5 s.
"Set" and  flash.
2. Press **MODE**.
3. Use ▲/▼ to select 12 or 24 hour mode.
4. **OK** to confirm
5. Use ▲/▼ to select the current hour.
6. **OK** to confirm
7. Use ▲/▼ to select the current minute.
8. **OK** to confirm
9. Use ▲/▼ to select the current day of the week.
Meaning: **d.1** = Monday ... **d.7** = Sunday
10. **OK** to confirm
11. Use ▲/▼ to select the current month.
12. **OK** to confirm
13. Use ▲/▼ to select the current day.
14. **OK** to confirm
15. Use ▲/▼ to select the current year.
16. **OK** to confirm
The default display appears.

Further details regarding the individual steps (cont.)

Making the settings for operation with outside temperature sensor or room temperature sensor

If an outside temperature sensor or room temperature sensor has been connected to the control unit:

Set the function at the control unit.

1. Hold down **MODE** and **▲** simultaneously for approx. 5 s.
 - "SEt" and  flash
 - "PL:1" is shown on the additional display
 -  is shown in the upper display area
2. Press **MODE**.
3. Use **▲/▼** to select "P10".
4. **OK** to confirm
5. Use **▲/▼** to select access code 2 for parameter level 2.
6. **OK** to confirm
 - "PL:2" is shown on the additional display
 -  is shown in the upper display area
7. **MODE** to confirm
8. Use **▲/▼** to select "P14".
9. **OK** to confirm
10. Use **▲/▼** to select the function.
 - Outside temperature sensor: "OTC"
 - Room temperature sensor: "RTC"
11. **OK** to confirm
12. **MODE** to exit the parameter level.

Activating/deactivating WLAN module

Connect control unit to WLAN

If the system user wishes to access the heating system with a mobile device, activate the integrated WLAN module.


Activate WLAN module via key combination

Press and hold **MODE**, **▲** and **OK** at the same time for at least 5 seconds until "ON" or "OFF" appears on the display. Release the buttons and the change will be accepted.

Activate WLAN module via menu

Press the following buttons:


1. Press and hold **MODE** and **▲** at the same time for at least 5 seconds until the following display appears:




Further details regarding the individual steps (cont.)

2. Press **MODE** within 5 seconds until the following display appears:





3. ▲ until **P06** is displayed.
4. **OK** to confirm
5. ▲/▼ for ON.
Symbol  is displayed.



6. **OK** to confirm
7. **MODE**, to exit the settings mode.

Fault messages during activation

( and  flashing)

- **H01**: Internal error
- **H02**: Internal error
- **H03**: Excess temperature WLAN module



Connecting the heating system to WLAN and the Viessmann server



Register the heating system on the Viessmann server via the relevant app.

Display shows:

- The message **"COnn"** is displayed while the connection is being established
- If the WLAN module fails to register on the router, **"FAIL"** is displayed.
- When the WLAN module registers successfully on the router, **"PASS"** is displayed.
- If the WLAN module is active in access point mode, **"AP"** is displayed.

Faults during operation

 and  flash and **"FAC"** is displayed: Connection fault between WLAN module and control unit.

If faults occur when connecting to the internet,  and  flash together.








For more information, see messages in the app.

Making the settings for operation with external extension

If an external extension has been connected to the control unit:
Set the function at the control unit.

1. Hold down **MODE** and ▲ simultaneously for approx. 5 s.

Further details regarding the individual steps (cont.)

- **"SEt"** and  flash
 - **"PL:1"** is shown on the additional display
 - 1  is shown in the upper display area
2. Press **MODE**.
 3. Use ▲/▼ to select **"P10"**.
 4. **OK** to confirm
 5. Use ▲/▼ to select access code **2** for parameter level 2.
 6. **OK** to confirm
 - **"PL:2"** is shown on the additional display
 - 2  is shown in the upper display area
 7. **MODE** to confirm
 8. Use ▲/▼ to select **"P27"**.
 9. **OK** to confirm
 10. Use ▲/▼ to select **"On"**.
 11. **OK** to confirm
 12. **MODE** to exit the parameter level.
 - If communication between the control unit and the extension is working,  flash simultaneously.
 - If communication between the control unit and the extension is faulty,  flash alternately. Fault **"CC"** is shown.
Repeat the steps and set value **"OFF"** in **"P27"**. Then repeat the steps once more and select value **"On"** again.

The functions of the external extension are set in **"P40"** to **"P49"**.






Installation and service instructions

External extension

Switching off DHW heating

If the boiler is to be operated without DHW heating (conventional gas boiler): Switch off the function at the control unit.

1. Hold down **MODE** and ▲ simultaneously for approx. 5 s.
 - **"SEt"** and  flash
 - **"PL:1"** is shown on the additional display
 - 1  is shown in the upper display area
2. Press **MODE**.
3. Use ▲/▼ to select **"P10"**.
4. **OK** to confirm
5. Use ▲/▼ to select access code **2** for parameter level 2.
6. **OK** to confirm
 - **"PL:2"** is shown on the additional display
 - 2  is shown in the upper display area
7. **MODE** to confirm

Further details regarding the individual steps (cont.)

8. Use ▲/▼ to select "**P13**".
9. **OK** to confirm
10. Use ▲/▼ to select "**On**".
11. **OK** to confirm
12. **MODE** to exit the parameter level. DHW heating and all functions associated with it are deactivated.

Note


*If DHW heating is to be activated again, set value "**OFF**".*

Checking the static pressure and supply pressure




Danger

CO formation as a result of incorrect burner adjustment can have serious health implications. Always carry out a CO test before and after work on gas appliances.



2. Undo screw (A) inside test connector "IN" on the gas train, but do not remove it. Connect the pressure gauge.
3. Open the gas shut-off valve.
4. Check the static pressure.
Set value: Max. 30 mbar (3.0 kPa)
5. Start the boiler.

Note

*During commissioning, the appliance can enter a fault state because of airlocks in the gas line. After approx. 5 s, press **RESET** to reset the burner:
Press **MODE** and **OK** simultaneously and hold until  flashes.*

6. Check the supply (flow) pressure.
Set value: 20 mbar (2.0 kPa)

Note

Use a suitable measuring device with a resolution of at least 0.1 mbar (0.01 kPa) to check the supply pressure.

1. Close the gas shut-off valve.
7. Implement measures as indicated in the table below.

Further details regarding the individual steps (cont.)

8. Shut down the boiler and close the gas shut-off valve. Remove the pressure gauge and seal test connector (A) with screw.
9. Open the gas shut-off valve and start the appliance.



Danger

Gas escaping from the test connector leads to a risk of explosion.


Check gas tightness at test connector (A).

Supply pressure (flow pressure)	Measures
Below 15 mbar (1.5 kPa)	Do not commission the appliance, and notify the gas supply utility.
15 to 30 mbar (1.5 - 3.0 kPa)	Start the boiler.
Above 30 mbar (3.0 kPa)	Connect the separate gas pressure governor upstream of the system and set the pre-charge pressure to 20 mbar (2.0 kPa). Notify the gas supply utility.

Checking the CO₂ content

Note

Operate the appliance with uncontaminated combustion air to prevent operating faults and damage.



2. Start the boiler and check all gas equipment for leaks.



Danger

Escaping gas leads to a risk of explosion.


Check gas equipment for leaks.


1. Connect a flue gas analyser at flue gas port (A) on the flue bend.

Further details regarding the individual steps (cont.)


3. Setting the upper heating output

Ensure heat is being drawn off by the heating system.

1. Press **MODE** and **▲** simultaneously and hold for approx. 5 s
 - "Set" is displayed
 -  flashes
 - "PL:1" is shown on the additional display
2. Press **MODE**
"P01" is shown on the additional display
3. **OK** to confirm
4. Use **▲** to select "ON"
5. **OK** to confirm
6. Press **MODE**
"LO" is shown on the additional display
7. Use **▲/▼** to select "HI"
The burner now operates at the upper heating output





Note

*Operation with the upper or lower rated heating output is automatically reset after approx. 30 min, or press **MODE** and **OK** simultaneously and hold until  flashes.*

4. Measure the CO₂ content for the upper heating output.
The CO₂ content must be between 7.0 and 10.5 %.

5. Select the lower heating output:

Use **▲/▼** to switch directly between the upper and lower heating output. "LO" and  are displayed.



6. Measure the CO₂ content for the lower heating output.
The CO₂ content must be between 0.3 and 0.9 % below the value of the upper heating output.
7.
 - If the CO₂ content is within the indicated range, continue with point 9.
 - If the CO₂ content is **not** within the indicated range, check the balanced flue system for tightness; remedy any leaks.
Replace the gas train if required.
8. Measure the CO₂ content for the upper and lower heating output again.
9. Shut down the boiler, remove the flue gas analyser and close flue gas test port (A).




Danger


Flue gas can lead to life threatening poisoning.
It is essential to close the port again with the plug.

Further details regarding the individual steps (cont.)

Limiting the maximum heating output

1. Hold down **MODE** and **▲** simultaneously for approx. 5 s.
 - "SET" and  flash.
 - "PL:1" is shown on the additional display.
2. Press **MODE**.
3. Use **▲/▼** to select "**P03**".
4. **OK** to confirm
5. Use **▲/▼** to set the max. heating output in % of the upper rated heating output.
Setting range 40 to 100 %
6. **OK** to confirm
7. **MODE** to exit the parameter level.

Removing the burner



1. Switch OFF the power supply.
2. Shut off the gas supply.

Further details regarding the individual steps (cont.)

3. Disconnect the cables from fan motor (A), gas train (B) and electrodes (C).
4. Disconnect Venturi extension (D) from the fan.
5. Undo gas supply pipe fitting (E).
6. Undo 4 screws (F) and remove the burner.




Please note

To prevent damage, never rest the burner on the burner gauze assembly.

Checking the burner gasket and burner gauze assembly

Check burner gasket (A) for damage and replace if necessary.

Replace the burner gauze assembly if it is damaged.





Further details regarding the individual steps (cont.)

1. Remove electrode (B).
2. Undo 2 Torx screws and remove thermal insulation ring (C).
3. Undo 2 Torx screws and remove burner gauze assembly (D) with gasket (E).
4. Insert and secure new burner gauze assembly (D) with new gasket (E).
Torque for fixing screws: 3.5 Nm
5. Mount thermal insulation ring (C).
Torque for fixing screws: 3.5 Nm
6. Fit electrode (B).
Torque for fixing screws: 4.5 Nm

Checking and adjusting the electrode

1. Check the electrode for wear and contamination.
2. Clean the electrode with a small brush (not a wire brush) or emery paper.
3. Check the electrode gaps. If the gaps are not as specified or the electrode is damaged, replace the electrode and gasket and align.
Tighten the electrode fixing screws to a torque of 4.5 Nm.



Further details regarding the individual steps (cont.)

Cleaning the heat exchanger



Please note

Scratches to the surfaces of the heat exchanger that come into contact with hot gas can result in corrosion damage. Brushing can cause deposits to become lodged in the gaps between the coils.

Never use brushes to clean the heating surfaces.



Please note


Prevent damage due to cleaning water.

Cover the control unit with suitable watertight material.

Note


Discolouration on the heat exchanger surface is a normal sign of use. It has no bearing on the function and service life of the heat exchanger.

The use of chemical cleaning agents is not required.



1. Use a vacuum cleaner to remove combustion residues from heating surface (A) of the heat exchanger.
2. Flush heating surface (A) with water.
3. Check condensate drain. Clean the trap: See the following chapter.
4. Flush the heating surface again with water. This will also fill the trap with water.

Condensate drain check and trap cleaning




1. Pull trap (A) upwards out of the drain connection.
2. Remove supply hose (B) from trap (A).
3. Clean trap (A).
4. Refit supply hose (B).
5. Refit trap (A) to the drain connection.

Further details regarding the individual steps (cont.)

6. Fill trap (A) with water. For this, pour approx. 0.3 l of water into the combustion chamber.
7. Check that condensate can drain freely and that the connections are tight.

Installing the burner



1. Fit the burner and diagonally tighten 4 screws (A) to a torque of 8.5 Nm.
2. Insert new gasket. Secure the fitting of gas supply pipe (B).
3. Refit Venturi extension (C) to the fan.
4. Fit the cables to fan motor (D), gas train (E) and ignition unit (F).

Further details regarding the individual steps (cont.)

5. Re-establish gas supply. Switch ON the power supply.
6. Check the gas connections for leaks.



Danger

Escaping gas leads to a risk of explosion.
Check the fitting for gas tightness.



Please note

The use of leak detection spray can result in faulty operation.
Leak detection spray must not come into contact with electrical contacts or block the diaphragm opening on the gas valve.

Checking the diaphragm expansion vessel and system pressure

Carry out this test on a cold system.

1. Switch ON the control unit. Close the gas shut-off valve.
2. Use ▲/▼ to select "IF00"
The main display shows the current pressure in MPa.
3. Drain the system or close the cap valve on the expansion vessel and reduce the pressure until 0 MPa is shown.
4. If the pre-charge pressure of the expansion vessel is lower than the static system pressure, top up with nitrogen until the pre-charge pressure is 0.01 to 0.02 MPa higher than the static system pressure.
5. Top up with water (see page 35) until the charge pressure of the cooled system is at least 0.08 MPa, and is 0.01 to 0.02 MPa higher than the pre-charge pressure of the expansion vessel.
Permiss. operating pressure:
(0.3 MPa)

Further details regarding the individual steps (cont.)

Checking gas equipment for leaks at operating pressure



Danger

Escaping gas leads to a risk of explosion.
Check gas equipment for leaks.


Please note

The use of leak detection spray can result in faulty operation. Leak detection spray must not come into contact with electrical contacts or block the diaphragm opening on the gas valve.

Mounting the front panel



1. Hook the front panel into place.



Further details regarding the individual steps (cont.)

2. Tighten screws on the underside of the boiler.

Instructing the system user

- Instruct the system user about operation and the safety regulations.
- Hand over the operating instructions to the system user.
- After installation the installer must identify the flue system and provide the operator with the safety instructions required for the correct and safe use of the system.

Main parameter level



Calling up the main parameter level:

1. Press **MODE** to select the required settings.
2. Use **▲/▼** to select the required value.
 - Use **OK** to confirm and exit the menu.
 - Or
 - Press **MODE** to confirm and to change to the next setting.



Note

The settings shown depend on the equipment level of the heating system.



Set DHW temperature

Symbols		Main display	Additional display
Flashing	constant		
		Temperature in °C	



Set heating water temperature

Symbols		Main display	Additional display
Flashing	constant		
		Temperature in °C	





Set room temperature

Symbols		Main display	Additional display
Flashing	constant		
		Temperature in °C	

Heating curve




Symbols		Main display	Additional display
Flashing	constant		
		Heating curve "1" to "6" or "dEF" for factory setting	

Time program, switching DHW heating on/off




Symbols		Main display	Additional display
Flashing	constant		
		"SET"	"On"
			or
			"OFF"

Main parameter level (cont.)





Time program, switching central heating mode on/off

Symbols		Main display	Additional display
Flashing	constant		
  <p>p</p>		"SEt"	"On" or "OFF"





Time program, set heating water temperature

Symbols		Main display	Additional display
Flashing	constant		
  <p>p</p>		Temperature in °C	"L:1" and I for stage 1 or "L:2" and next to it II for stage 2


Time program, set room temperature for operation with room temperature sensor

Symbols		Main display	Additional display
Flashing	constant		
  <p>p</p> 		Temperature in °C	


Time program, heating curve for operation with outside temperature sensor

Symbols		Main display	Additional display
Flashing	constant		
  <p>p</p> 		Heating curve "1" to "6" or "dEF" for facto- ry setting	

Winter mode


Symbols		Main display	Additional display
Flashing	constant		
		"SEt"	

Summer mode

Symbols		Main display	Additional display
Flashing	constant		
		"SEt"	




Main parameter level (cont.)

Standby mode

Symbols		Main display	Additional display
Flashing	constant		
		"SET"	

Parameter level 1

Calling up parameter level 1:

1. Hold down **MODE** and **▲** simultaneously for approx. 5 s.
 - "SET" and  flash.
 - "PL:1" is shown on the additional display.
 -  is shown in the upper display area
2. Press **MODE**.
 - "P01" is shown on the main display.
 -  is shown and does not flash.
3. Use **▲/▼** to select the parameter.
4. **OK** to confirm

Emissions test mode

Parameter	Possible change	Main display	Additional display
"P01"	<p>"OFF" Test mode switched off</p> <p>"On" Test mode switched on</p> <p>With test mode switched on, use ▲/▼ to change between upper and lower heating output.</p>	<p>With test mode switched on:</p> <ul style="list-style-type: none"> ■ Temperature in °C 	<p>With test mode switched on:</p> <p>"LO" For lower heating output</p> <p>"HI" For upper heating output</p>

Filling and venting function


Parameter	Possible change	Main display	Additional display
"P02"	<p>"OFF" Function switched off</p> <p>"On" Function switched on</p>	<p>With test mode switched on:</p> <ul style="list-style-type: none"> ■ "Air" 	<p>With test mode switched on:</p> <ul style="list-style-type: none"> ■ Remaining time in min

Parameter level 1 (cont.)

Limiting the maximum heating output

Parameter	Possible change	Main display	Additional display
"P03"	Max. heating output in % of the upper rated heating output. Setting range 40 to 100 %	Heating output in %	

Activating WLAN module

Parameter	Possible change	Main display	Additional display
"P06"	"OFF" WLAN module switched off "On" WLAN module switched on	When "ON", the symbol appears: 	

Activate OpenTherm/WiFi access

Parameter	Possible change	Main display	Additional display
"P07"	<p>0 OpenTherm basic function (delivered condition). Adjustment recommended. Simple room thermostat activated (boiler on/off). Read only WiFi.</p> <p>1 OpenTherm basic function. Simple room thermostat activated (boiler on/off). Read and write WiFi.</p> <p>2 OpenTherm fully activated. Read only WiFi.</p> <p>3 OpenTherm fully activated. Read and write WiFi.</p>		

Parameter level 1 (cont.)

Note

OpenTherm basic function: Room thermostat works only as a "remote control (on/off)". All time programs and temperature settings of the room thermostat are deactivated. Time programs can be set via the boiler control unit operating menu or the app.

*OpenTherm fully activated: The OpenTherm room thermostat functions as master, all relevant functions (time programs, temperature settings) on the programming unit of the boiler control unit and via the app are **deactivated!** If the WiFi module is activated via parameter P06, "writing" is activated automatically.*

Vitotrol 100, type UTDB-RF2

Parameter	Possible change	Main display	Additional display
"P08"	0 Without Vitotrol 100, type UTDB-RF2 1 With Vitotrol 100, type UTDB-RF2		



Maintenance reminder

Parameter	Possible change	Main display	Additional display
"P09"	Deactivate/activate		

Access to parameter level 2

Parameter	Possible change	Main display	Additional display
"P10"	Access code setting for parameter level 2	Access code	

Parameter level 2

- Hold down **MODE** and **▲** simultaneously for approx. 5 s.
 - **"SEt"** and **🔊** flash
 - **"PL:1"** is shown on the additional display
 - **1**  is shown in the upper display area
- Press **MODE**.
- Use **▲/▼** to select **"P10"**.
- OK** to confirm
- Use **▲/▼** to select access code **2** for parameter level 2.
- OK** to confirm
 - **"PL:2"** is shown on the additional display
 - **2**  is shown in the upper display area
- MODE** to confirm
- Use **▲/▼** to select the parameter.



Parameter level 2 (cont.)

9. OK to confirm

Switching DHW heating on/off

Parameter	Possible change	Main display	Additional display
"P13"	"ON" DHW heating switched off		
	"OFF" DHW heating switched on		


External temperature sensor (room temperature sensor/outside temperature sensor)

Parameter	Possible change	Main display	Additional display
"P14"	"OFF" without temperature sensor		
	"OTC" with outside temperature sensor		
	"RTC" with room temperature sensor		


External extension

Parameter	Possible change	Main display	Additional display
"P27"	"OFF" without external extension		
	"On" with external extension		
"P40" to "P49"	See installation and service instructions for the external extension		


Function sequence and possible faults



Function sequence and possible faults (cont.)




Resetting the appliance

Press **MODE** and **OK** simultaneously and hold until  flashes (reset).


Overview of checks

Display	Area
IF	Status checks (current/set values), see page 62
Ct	Meter checks, see page 64
AL	Fault history (10 most recent fault messages) For the meaning of the fault messages, see "Fault display" from page 66



















 Time program for DHW heating and heating mode, see operating instructions.
The submenu for DHW heating is only displayed when a hot water time is set.

- Use ▲/▼ to select the required check.
 - The selected check is shown on the additional display.
 - The value to be checked is shown on the main display.
- Press **MODE** to select the required areas.

Status checks

Check	Display	Symbols	Constant
		Flashing	
Current system pressure	"IF00"		MPa
Actual heating water temperature	"IF01"		°C

Status checks (cont.)

Check	Display	Symbols	Constant
		Flashing	
Set heating water temperature	"IF02"		 °C
Set maximum heating output	"IF03"		%
Actual DHW temperature	"IF04"		°C
Set DHW temperature	"IF05"		 °C
DHW flow rate	"IF06"		
Actual collector temperature (only in conjunction with external extension)	"IF07"		 °C
Actual cylinder temperature, bottom (only in conjunction with external extension)	"IF08"		 °C 1 
Actual cylinder temperature, top (only in conjunction with external extension)	"IF09"		 °C 2 
Current outside temperature (for operation with outside temperature sensor)	"IF10"		°C
Current room temperature (for operation with room temperature sensor)	"IF10"		°C
Set heating curve (for operation with outside temperature sensor)	"IF11"		 
Set room temperature (for operation with room temperature sensor)	"IF11"		 °C 
Burner status	"IF12"		
Fan speed	"IF13"		
Current burner output	"IF14"		%
---	"IF15"		
Gas solenoid valve position ("On" or "OFF")	"IF16"		
Fan status ("On" or "OFF")	"IF17"		
Circulation pump status ("On" or "OFF")	"IF18"		
3-way diverter valve setting (heating mode, DHW or middle setting)	"IF19"		
---	"IF20"		

Status checks (cont.)

Check	Display	Symbols	
		Flashing	Constant
Cylinder type	"IF21"		
OpenTherm/WLAN access ("On" or "OFF")	"IF22"		

Meter checks















The display is split into 3 blocks.

Display "Ct01": "002"






Display "Ct02": "540"

Example:

Burner hours run: 2540 h



Check	Display	Symbols	
		Flashing	Constant
Control unit hours run (in thousands)	"Ct01"	  I	
Control unit hours run (in units)	"Ct02"	  0	
Burner hours run (in thousands)	"Ct03"	  I	
Burner hours run (in units)	"Ct04"	  0	
Ignition attempts (in millions)	"Ct05"	 II	
Ignition attempts (in thousands)	"Ct06"	 I	
Ignition attempts (in units)	"Ct07"	 0	
Heat demands for drinking water, demands for DHW (in millions)	"Ct08"	 II	
Heat demands for drinking water, demands for DHW (in thousands)	"Ct09"	 I	
Heat demands for drinking water, demands for DHW (in units)	"Ct10"	 0	


Meter checks (cont.)


Check	Display	Symbols	
		Flashing	Constant
Heat demands, heating mode (in millions)	"Ct11"	 II	
Heat demands, heating mode (in thousands)	"Ct12"	 I	
Heat demands, heating mode (in units)	"Ct13"	 0	
Faults (in thousands)	"Ct14"	 I	
Faults (in units)	"Ct15"	 0	

Fault display



Faults are indicated by a flashing fault code (e.g. "F30") and fault symbol  or .




Displayed fault code	System characteristics	Cause	Measures
06	Burner locked out	System pressure too low	Check the system pressure. If required, top up heating water (see page 35).
0A	Burner locked out	Gas supply pressure too low	Check the gas pressure and gas pressure switch (if installed)
0C	Standby	Mains voltage too low	Wait until the mains voltage returns to the normal range.
CC	Function at the external extension faulty	Communication between control unit and external extension interrupted	Check connecting cable between control unit and external extension
F02	Burner in a fault state	Temperature limiter has responded	Check heating system fill level. Check circulation pump. Vent the system. Press MODE and OK simultaneously and hold until  flashes (reset).

Fault display (cont.)






Displayed fault code	System characteristics	Cause	Measures
F03	Burner in a fault state	Flame signal is already present at burner start	Check ionisation electrode and connecting cable. Turn the ON/OFF switch off and back on again, or perform a reset – see F02.
F04	Burner in a fault state	Flame signal is not present	Check the ignition/ionisation electrodes and connecting cable, check the gas pressure, check the gas train, check the ignition and ignition module. Turn the ON/OFF switch off and back on again, or perform a reset – see F02.
F05	Burner in a fault state	Fan does not start when burner starts	Check the fan motor and connecting cables Turn the ON/OFF switch off and back on again, or perform a reset – see F02.
F07	Burner locked out	Lead break, water pressure sensor	Check the water pressure sensor Turn the ON/OFF switch ① off and back on again (or reset, see F02).
F08	Burner in a fault state	Gas solenoid valve relay blocked	Check relay, gas solenoid valve and connecting lead Turn the ON/OFF switch off and back on again, or perform a reset – see F02.
F10	Continuous operation	Short circuit, outside temperature sensor or room temperature sensor	Check the sensor (see page 72).



Fault display (cont.)

Displayed fault code	System characteristics	Cause	Measures
F18	Continuous operation	Lead break, outside temperature sensor or room temperature sensor	Check the sensor (see page 72).
F30	Burner locked out	Short circuit, boiler water temperature sensor	Check the boiler water temperature sensor (see page 73).
F38	Burner locked out	Lead break, boiler water temperature sensor	Check the boiler water temperature sensor (see page 73).
F51	No DHW heating	Short circuit, cylinder temperature sensor (gas condensing system boiler) or outlet temperature sensor (gas condensing combi boiler)	Check the sensor (see page 74).
F59	No DHW heating	Lead break, cylinder temperature sensor (gas condensing system boiler) or outlet temperature sensor (gas condensing combi boiler)	Check the sensor (see page 74).
F6F	WLAN connection interrupted	Communication between control unit and WLAN module interrupted	Check connecting cable between control unit and WLAN module. Check setting of parameter P06 and P07.
F70	Function at the external extension faulty	Short circuit, collector temperature sensor S1 at the external extension	Checking the sensor  Installation and service instructions for external extension

Fault display (cont.)

Displayed fault code	System characteristics	Cause	Measures
F78	Function at the external extension faulty	Lead break, collector temperature sensor S1 at the external extension	Checking the sensor  Installation and service instructions for external extension
F80	Function at the external extension faulty	Short circuit, lower cylinder temperature sensor S2 at the external extension	Checking the sensor  Installation and service instructions for external extension
F88	Function at the external extension faulty	Lead break, lower cylinder temperature sensor S2 at the external extension	Checking the sensor  Installation and service instructions for external extension
F90	Function at the external extension faulty	Short circuit, upper cylinder temperature sensor S3 at the external extension	Checking the sensor  Installation and service instructions for external extension
F98	Function at the external extension faulty	Lead break, upper cylinder temperature sensor S3 at the external extension	Checking the sensor  Installation and service instructions for external extension
Fb0	Burner locked out	Short circuit, flue gas temperature sensor	Check flue gas temperature sensor (see page 77).



Fault display (cont.)

Displayed fault code	System characteristics	Cause	Measures
Fb8	Burner locked out	Lead break, flue gas temperature sensor	Check flue gas temperature sensor (see page 77).
FF1	Burner locked out	Flue gas temperature too high	Check heating system fill level. Check circulation pump. Vent the system. Check flue system. Turn the ON/OFF switch off and back on again, or perform a reset – see F02.

Repairs



Please note

Residual water will escape when the boiler or one of the following components is fitted or removed:

- Water-filled pipework
- Heat exchanger
- Circulation pumps


- Plate heat exchanger
 - Components fitted in the heating water or DHW circuit.
- Water ingress can result in damage to other components.

Protect the following components against ingress of water:

- Control unit (in particular in the service position)
- Electrical components
- Plug-in connections
- Cables and leads

Repairs (cont.)


Removing the front panel




1. Undo the screws on the underside of the boiler. Do not remove.
2. Remove front panel.

Repairs (cont.)

Outside temperature sensor or room temperature sensor




- (A) Outside temperature sensor or room temperature sensor
- (B) Terminals on control unit enclosure




1. Open the control unit enclosure.
See page 25.
2. Disconnect leads from outside temperature sensor.
3. Check the sensor resistance and compare it to the curve.
4. In the event of severe deviation replace the sensor.

Repairs (cont.)

Boiler water temperature sensor



1. Disconnect leads from boiler water temperature sensor (A) 3 and check the resistance.



2. Check the sensor resistance and compare it to the curve.
3. In the case of severe deviation, drain the boiler on the heating water side and replace the sensor.




Danger

The sensor is immersed in the heating water (risk of scalding).


Drain the boiler before replacing the sensor.

Repairs (cont.)

Checking the cylinder temperature sensor (gas condensing system boiler)




1. Disconnect plug 5 from the cable harness and check the resistance.




2. Compare the sensor resistance to the curve.
3. In the event of severe deviation replace the sensor.

Repairs (cont.)

Checking the outlet temperature sensor (gas condensing combi boiler)



1. Disconnect leads from outlet temperature sensor (A) 4.
2. Check the sensor resistance and compare it to the curve.





3. In the event of severe deviation replace the sensor.
 - Shut off the cold water supply.
 - Drain the DHW line and the plate heat exchanger (on the DHW side).

Repairs (cont.)

Checking the temperature limiter


If the burner control unit cannot be reset after a fault shutdown although the boiler water temperature is below approx. 95 °C, check the temperature limiter.




1. Disconnect the leads from temperature limiter (A).
2. Check the continuity of the temperature limiter with a multimeter.
3. Remove faulty temperature limiter.
4. Install a new temperature limiter.
5. Press **MODE** and **OK** simultaneously and hold until  flashes (reset).

Repairs (cont.)

Checking the flue gas temperature sensor




1. Disconnect the leads from flue gas temperature sensor (A) 15.
2. Check the sensor resistance and compare it to the curve.



3. In the event of severe deviation replace the sensor.

Repairs (cont.)

Replace flow limiter and clean filter (gas condensing combi boiler)




1. Drain the boiler on the DHW side.
2. Undo the fitting on the cold water inlet (A).
3. Remove faulty flow limiter (B).
4. Select new flow limiter (B) according to the boiler serial no. (see type plate) and the following table.
5. Insert new flow limiter (B).
6. Remove filter (C), clean and re-fit.
7. Secure the fitting on the cold water inlet (A).

Serial no. (type plate)	Flow rate l/min	Colour
7538975	10	Blue
7538977	14	Pink

Repairs (cont.)

Checking or replacing the plate heat exchanger (gas condensing combi boiler)



- (C) Heating water flow
- (D) Heating water return
- (E) Cold water

- (F) DHW

1. Shut off and drain the boiler on the heating water and DHW sides.
2. Pivot the control unit downwards.
3. Undo 2 screws (A) on plate heat exchanger (B) and remove plate heat exchanger with gaskets.

Note

During and after removal, small amounts of water may trickle from the plate heat exchanger.


Repairs (cont.)

4. Check the connections on the DHW side for scaling; clean or replace the plate heat exchanger if required.
5. Check the connections on the heating water side for contamination; clean or replace the plate heat exchanger if required.
6. Install in reverse order using new gaskets.

Note

During installation, ensure the fixing holes are aligned and the gaskets are seated correctly. Fit the plate heat exchanger the right way round.

Checking the fuse




1. Switch OFF the power supply.
2. Open the control unit enclosure (see page 25).
3. Check fuse F1.

Weather-compensated operation

In weather-compensated mode (with connected outside temperature sensor), the boiler water temperature is regulated according to the outside temperature.

Heating curve for weather-compensated operation



Heating curve settings:

- Ⓐ = 1
- Ⓑ = 2
- Ⓒ = 3
- Ⓓ = 4

Ⓔ = delivered condition

Ⓕ = 5

Ⓖ = 6

For heating curve setting, see page 55.

Weather-compensated operation (cont.)

Frost protection function

The boiler must be switched on to ensure frost protection.

Boiler frost protection

Frost protection without outside temperature sensor

If the boiler water temperature falls below 8 °C, the internal circulation pump switches on until the boiler water temperature reaches 12 °C. The 3-way diverter valve is in the central heating position. If the boiler water temperature falls below 5 °C, the burner also switches on until the boiler water temperature reaches 28 °C.


Frost protection with connected outside temperature sensor

If the outside temperature falls below 1 °C, the internal circulation pump switches on. The 3-way diverter valve is in the central heating position. If the outside temperature exceeds 3 °C, the internal circulation pump runs on for a fixed time. If the boiler water temperature falls below 5 °C, the burner also switches on until the boiler water temperature reaches 28 °C.

DHW cylinder frost protection

If the cylinder temperature falls below 5 °C, the frost protection function is enabled. The burner remains on until the cylinder temperature reaches 7.5 °C.

Connection and wiring diagram



- (A) PCB inside the control unit
- (B) Power supply
- CN3 External extension AUX 900101
- X3 Gas pressure switch (accessories)
- X6 Gas train

- X7
- (C) Outside temperature sensor or room temperature sensor **1** (accessories) or
- (D) Room temperature controller (OpenTherm accessories)
- X8 Fan
- X9 Internal circulation pump
- X11 WLAN module

Connection and wiring diagram (cont.)


X13	Power supply WLAN module (24 V)	15	Flue gas temperature sensor
		20	Circulation pump 230 V~
T5/TR1-1	Ignition/ionisation	30	Motor, diverter valve
3	Boiler water temperature sensor	35	Gas solenoid valve
		47	Temperature limiter
4	Outlet temperature sensor (gas condensing combi boiler)	100 A	Fan control
		149	Flow sensor
5	Cylinder temperature sensor (gas condensing system boiler)	163	Water pressure sensor

Ordering parts

The following information is required:

- Serial no. (see type plate (A))
- Assembly (from this parts list)
- Position number of the individual part within the assembly (from this parts list)


Overview of assemblies



- (A) Type plate
- (B) Casing assembly
- (C) Heat cell assembly

- (D) Hydraulic assembly
- (E) Control unit assembly
- (F) Miscellaneous assembly


Casing assembly



Casing assembly (cont.)

Pos.	Part
0001	Front panel
0002	Profiled seal
0003	Viessmann logo
0004	Strain relief, upper part
0005	Air box floor
0006	Wall mounting bracket


Heat cell assembly



Heat cell assembly (cont.)

Pos.	Part
0001	Gasket DN 60
0002	Boiler flue connection
0003	Boiler flue connection plug
0004	Flue gasket
0005	Flue gas temperature sensor
0006	Heat exchanger
0007	Condensate hose
0008	Splash trap
0009	Tee connector
0010	Gas connection
0011	Gasket A 17 x 24 x 2 (5 pce)
0012	Burner (see burner assembly)
0013	Thermal insulation block
0014	Heat exchanger mounting bracket (set)
0015	O-ring 20.63 x 2.62 (5 pce)
0016	Condensate hose 400
0017	Corrugated hose 19 x 800 with ferrule/bend


Burner assembly



Burner assembly (cont.)

Pos.	Part
0001	Burner gasket \varnothing 187 (wearing part)
0002	Thermal insulation ring
0003	Cylinder burner gauze assembly
0004	Burner gauze assembly gasket
0005	Burner door
0006	Gasket, ionisation electrode (5 pce)
0007	Ignition/ionisation electrode (wearing part)
0008	Gasket, burner door flange (wearing part)
0009	Radial fan NRG 118
0010	Gas valve
0011	Venturi extension (wearing part)
0012	Gasket set


Hydraulic assembly



Hydraulic assembly (cont.)

Pos.	Part
0001	Diaphragm expansion vessel
0002	Padding profile, diaphragm expansion vessel
0003	Gaskets (set)
0004	Connection line, diaphragm expansion vessel G 1/2
0005	Connection elbow HR (heating return)
0006	Profile hose HR (heating return)
0007	Spring clip DN 25 (5 pce)
0008	Clip Ø 10 (5 pce)
0009	Clip Ø 8 (5 pce)
0010	O-ring 20.63 x 2.62 (5 pce)
0011	Temperature sensor
0012	Profile hose HV (heating flow)
0013	Pressure sensor
0014	Pump hose connection adaptor
0015	Thermal circuit breaker
0016	Connection elbow HV (heating flow)
0017	Hydraulics (see hydraulic assembly, system or combi boiler)


Hydraulic assembly, system boiler



Hydraulic assembly, system boiler (cont.)

Pos.	Part
0001	Quick-action air vent valve
0004	Safety valve 3 bar
0005	Fuse elements (set)
0006	Pump motor
0008	Stepper motor
0009	Cartridge, stepper motor
0012	Heating flow
0013	Gaskets (set)
0016	Return unit, system boiler
0017	Circulation pump
0019	Diaphragm grommet
0020	Overflow line
0021	Bypass valve


Hydraulic assembly, combi boiler



Hydraulic assembly, combi boiler (cont.)

Pos.	Part
0001	Quick-action air vent valve
0002	Plate heat exchanger
0003	Profiled gasket (4 pce)
0004	Safety valve 3 bar
0005	Fuse elements (set)
0006	Pump motor
0007	Flow switch (set)
0008	Stepper motor
0009	Cartridge, stepper motor
0010	Flow limiter
0011	DHW supply adaptor with filter
0012	Flow unit, combi boiler
0013	Gaskets (set)
0014	Fill valve
0015	Temperature sensor
0016	Return unit
0017	Circulation pump
0018	Size 15 filling key
0019	Diaphragm grommet
0020	Bypass valve


Control unit assembly



Control unit assembly (cont.)

Pos.	Part
0001	VBC LCV control unit
0002	Clip hinge
0003	Profiled seal
0004	Cable harness X1/100
0005	Connecting cable, gas valve
0006	Fan connecting cable 100
0007	Power cable, stepper motor
0008	Connecting cable X7
0009	Fuse, 2.5 A (slow), 250 V (10 pce)
0010	Cable tie (10 pce)
0011	Vitodens 100 PCB
0012	WLAN module
0013	WLAN module connecting cable

Miscellaneous assembly



Pos.	Part
0001	Touch-up spray paint, white, 150 ml
0002	Touch-up paint stick, white
0003	Special grease
0004	Installation and service instructions
0005	Operating instructions

Specification

Gas condensing system boiler

Type		LN1GBQ 18-CC	LN1GBQ 24-CC	LN1GBQ 33-CC
Rated heat input (heating mode)	kW	6.1 – 17.8	6.1 – 24.3	8.2 – 32.7
Rated heat input (DHW heating)	kW	6.1 – 17.8	6.1 – 24.3	8.2 – 32.7
Rated heating output in heating mode (T_F/T_R 50/30 °C)	kW	6.5 – 19	6.5 – 26	8.8 – 35
Rated heating output during DHW heating (T_F/T_R 80/60 °C)	kW	5.9 – 17.3	5.9 – 23.7	8.0 – 31.9
Sound power level				
At full load (100 %)	dB (A)	< 49	< 49	< 49
At partial load (30 %)	dB (A)	< 37	< 37	< 40
Efficiency				
At full load (100 %)				
■ T_F/T_R 80/60 °C	%	99.0	99.5	98.0
■ T_F/T_R 50/30 °C	%	106.5	107.0	106.9
At partial load (30 %) T_F/T_R 50/30 °C	%	105.9	106.5	105.6
Gas throughput relative to max. heating output Natural gas 12T	m ³ /h	1.9	2.6	3.5
Gas supply pressure Natural gas 12T	Pa	2000	2000	2000
NOx class		5	5	5
Power consumption				
Max.	W	81	113	141
Without circulation pump	W	20	30	42
Boiler water capacity	l	2.8	2.8	3.4
Diaphragm expansion vessel				
Capacity	l	6	6	6
Pre-charge pressure	MPa	0.1	0.1	0.1
Permiss. operating pressure (heating water side)				
Min.	MPa	0.08	0.08	0.08
Max.	MPa	0.3	0.3	0.3
Heating water temperature				
Min.	°C	20	20	20
Max.	°C	80	80	80
DHW temperature				
Min.	°C	30	30	30
Max.	°C	60	60	60

Specification (cont.)

Type		LN1GBQ 18-CC	LN1GBQ 24-CC	LN1GBQ 33-CC
Rated heat input (heating mode)	kW	6.1 – 17.8	6.1 – 24.3	8.2 – 32.7
Rated heat input (DHW heating)	kW	6.1 – 17.8	6.1 – 24.3	8.2 – 32.7
Flue gas parameters				
Flue gas temperature at 30 °C heating water return temperature	°C	45	45	45
Flue gas temperature at 60 °C heating water return temperature	°C	68	68	70
Flue gas mass flow rate at max. heating output	m³/h	30.1	41.1	56.9
Flue gas mass flow rate at min. heating output	m³/h	14.6	14.6	17.6
Balanced flue connection	Ø mm	60/100	60/100	60/100
Rated voltage	V~	220	220	220
Rated frequency	Hz	50	50	50
Rated current	A~	2.0	2.0	2.0
IP rating		IPX4D	IPX4D	IPX4D
Protection class		I	I	I
Internal fuse	A	2.5	2.5	2.5
Permissible ambient temperature				
■ During operation	°C	0 to +40 °C	0 to +40 °C	0 to +40 °C
■ During storage and transport	°C	-20 to +65 °C	-20 to +65 °C	-20 to +65 °C
Dimensions				
Height	mm	700	700	700
Width	mm	400	400	400
Depth	mm	350	350	350
Weight	kg	34	34	36

Gas condensing combi boiler

Type		LL1GBQ24- CC	LL1GBQ33- CC
Rated heat input (heating mode)	kW	6.1 – 24.3	8.2 – 32.7
Rated heat input (DHW heating)	kW	6.1 – 30.5	8.2 – 36.5
Rated heating output in heating mode (T _F /T _R 50/30 °C)	kW	6.5 – 26	8.8 – 35
Rated heating output during DHW heating (T _F /T _R 80/60 °C)	kW	5.9 – 29.3	8.0 – 35.0

Specification (cont.)

Type		LL1GBQ24- CC	LL1GBQ33- CC
Rated heat input (heating mode)	kW	6.1 – 24.3	8.2 – 32.7
Rated heat input (DHW heating)	kW	6.1 – 30.5	8.2 – 36.5
Sound power level			
At full load (100 %)	dB (A)	< 50	< 51
At partial load (30 %)	dB (A)	< 37	< 40
Efficiency			
At full load (100 %)			
■ T _F /T _R 80/60 °C	%	99.5	97.6
■ T _F /T _R 50/30 °C	%	106.7	105.9
At partial load (30 %) T _F /T _R 50/30 °C	%	105.8	105.6
Gas throughput relative to max. heating output	m ³ /h	2.6	3.5
Natural gas 12T			
Gas supply pressure	Pa	2000	2000
Natural gas 12T			
NOx class		5	5
Power consumption			
Max.	W	124	150
Without circulation pump	W	41	51
Boiler water capacity	l	2.9	3.6
Diaphragm expansion vessel			
Capacity	l	6	6
Pre-charge pressure	MPa	0.1	0.1
Permiss. operating pressure (heating water side)			
Min.	MPa	0.08	0.08
Max.	MPa	0.3	0.3
Heating water temperature			
Min.	°C	20	20
Max.	°C	80	80
Operating pressure (on the DHW side)			
Min.	MPa	0.1	0.1
Max.	MPa	1.0	1.0
Nominal water flow rate for DHW heating (ΔT = 30 K)	l/min	12.4	17.0
DHW temperature			
Min.	°C	30	30
Max.	°C	57	57
Flue gas parameters			


Specification (cont.)

Type		LL1GBQ24-CC	LL1GBQ33-CC
Rated heat input (heating mode)	kW	6.1 – 24.3	8.2 – 32.7
Rated heat input (DHW heating)	kW	6.1 – 30.5	8.2 – 36.5
Flue gas temperature at 30 °C heating water return temperature	°C	45	45
Flue gas temperature at 60 °C heating water return temperature	°C	68	70
Flue gas mass flow rate at max. heating output	m³/h	41.1	56.9
Flue gas mass flow rate at min. heating output	m³/h	14.6	17.6
Balanced flue connection	Ø mm	60/100	60/100
Rated voltage	V~	220	220
Rated frequency	Hz	50	50
Rated current	A~	2.0	2.0
IP rating		IPX4D	IPX4D
Protection class		I	I
Internal fuse	A	2.5	2.5
Permissible ambient temperature			
■ During operation	°C	0 to +40 °C	0 to +40 °C
■ During storage and transport	°C	-20 to +65 °C	-20 to +65 °C
Dimensions			
Height	mm	700	700
Width	mm	400	400
Depth	mm	350	350
Weight	kg	35	38

Specification (cont.)

Residual head of the integral circulation pump


UPS 15-50 (rated heating output 19 kW)



- (A) Stage 1
- (B) Stage 2
- (C) Stage 3

Specification (cont.)


UPS 15-60 (rated heating output 26 kW)



- Ⓐ Stage 1
- Ⓑ Stage 2
- Ⓒ Stage 3

Specification (cont.)

UPS 15-70 (rated heating output 35 kW)



- Ⓐ Stage 1
- Ⓑ Stage 2
- Ⓒ Stage 3

Manufacturer's declaration for Vitodens 100 CC

We, Viessmann Heating Technology Dachang Co., Ltd., declare as sole responsible body, that the product **Vitodens 100 CC** complies with the following standards:

GB25034-2010
CECS215:2006

CJ/T395-2012

This product meets the requirements of the efficiency standard GB20665-2015 and is classified as an energy saving product.

Dachang, 1 January 2017

Viessmann Heating Technology
Dachang Co., Ltd.



Arndt Fingerhut

Keyword index

B

Boiler water temperature sensor	73
Burner gasket.....	48
Burner gauze assembly.....	48
Burner installation.....	51
Burner removal.....	47

C

Checks.....	62
CO ₂ content check.....	45
Combustion chamber cleaning.....	50
Commissioning.....	35
Condensate.....	21
Condensate drain.....	21, 50
Connection diagram.....	83
Connections.....	13, 18
Control unit, closing.....	32
Control unit, opening.....	25
Cylinder temperature sensor	74

D

Date, setting.....	40
DHW heating, switching off.....	43
Diagnostics.....	61
Diaphragm expansion vessel.....	35, 52
Dimensions.....	13

E

Electrical connections.....	26
External extension	
– Setting.....	42

F

Fault code.....	66
Fault display.....	66
Fault message.....	66
Filling function.....	35
Fill valve.....	37
Fill water.....	35
Fittings, connecting.....	18
Flow limiter.....	78
Flue gas connection.....	22
Flue gas temperature sensor.....	77

Flue pipe.....	22
Front panel, mounting.....	53
Front panel removal.....	17
Frost limit.....	82
Frost protection.....	82
Function sequence.....	61
Fuse.....	80

G

Gas connection.....	19
Gas supply pressure.....	44
Gas train.....	44

H

Heat exchanger cleaning.....	50
Heating output, limiting.....	47

I

Ignition.....	49
Ignition electrode.....	49
Installation preparations.....	14
Instantaneous water heater.....	79
Ionisation electrode.....	49

L

Lower heating output.....	46
---------------------------	----

O

OpenTherm	
– Connection.....	30
Outlet temperature sensor.....	75
Outside temperature sensor.....	27, 72
– Setting.....	41

P

Plate heat exchanger.....	79
Power supply.....	32
Pressure in the system.....	52
Product description.....	12
Product information.....	12

Keyword index (cont.)**R**

Reset.....	62
Room temperature controller.....	28, 29
Room temperature sensor.....	72
– Setting.....	41

S

Safety chain	76
Safety valve.....	21
Specification.....	102, 103
Static pressure.....	44
Supply pressure.....	44
Switching off DHW.....	43
System, filling.....	35
System pressure.....	52

T

Temperature limiter.....	76
Time, setting.....	40
Trap.....	21, 50
Troubleshooting.....	70

U

Unlocking.....	62
----------------	----

V

Ventilation air pipe.....	22
Venting.....	39
Vitotrol 100	
– Connection type UTDB.....	28
– Connection type UTDB-RF.....	29

W

Wall mounting.....	15
Wall mounting bracket.....	15
Water quality.....	35
Water side connections.....	18
Weather-compensated operation.....	81
WLAN	
– faults.....	42
WLAN module	
– activate.....	41

Applicability

Serial No.:

7637257	7637258
7637261	7639524
7639527	7639528

7637259
7639525

7637260
7639526



Viessmann Werke GmbH & Co. KG
D-35107 Allendorf
Telephone: +49 6452 70-0
Fax: +49 6452 70-2780
www.viessmann.com

Viessmann China Ltd.
Unit 16,17/F., Millennium City 2
378 Kwun Tong Road
Kwun Tong, Kowloon, Hong Kong
Tel: (852) 2544 0807
Fax: (852) 2544 0747
www.viessmann.com

5837148 Subject to technical modifications.