



**Flamco**



# Flamcomat, Flexcon M-K Installation and operating instructions Supplementary document

ENG SPC module, volume / pressure analogue





<b>BE</b>	Flamco Belux J. Van Elewijckstraat 59 B -1853 Grimbergen	+32 2 476 01 01	info@flamco.be
<b>CH</b>	Flamco AG Fännring 1 6403 Küsnacht	+41 41 854 30 50	info@flamco.ch
<b>CZ</b>	Flamco CZ U silnice 949 161 00 Praha 6	+420 602 200 569	info@flamco.cz
<b>DE</b>	Flamco GmbH Steinbrink 3 42555 Velbert	+49 2052 887 04	info@flamco.de
<b>DK</b>	Flamco Tonsbakken 16-18 DK-2740 Skovlunde	+45 44 94 02 07	info@flamco.dk
<b>FR</b>	Flamco s.a.r.l. BP 77173 95056 CERGY-PONTOISE cedex	+33 1 34 21 91 91	info@flamco.fr
<b>HU</b>	Flamco Kft. (A Pest Megyei Bíróság mint Cégbíróság, Cg.13-09-136479) H - 2330 Dunaharaszti, Jedlik Ányos út 25	+36 24 52 61 31	info@flamco.hu
<b>NL</b>	Flamco B.V. Postbus 502 3750 GM Bunschoten	+31 33 299 75 00	support@flamco.nl
<b>PL</b>	Flamco Sp. z o. o. ul. Akacjowa 4 62-002 Suchy Las	+48 616 5659 55	info@flamco.pl
<b>SE</b>	Flamco Sverige Kungsgatan 14 541 31 Skövde	+46 500 42 89 95	VVS@flamco.se
<b>UAE</b>	Flamco Middle East PO Box 262636 Jebel Ali, Dubai	+971 4 881 95 40	info@flamco-gulf.com
<b>UK</b>	Flamco Ltd Washway Lane- St Helens Merseyside WA10 6PB	+44 1744 74 47 44	info@flamco.co.uk

## Contents

1. Appropriate use.....	4
2. Equipment, installation of module.....	4
3. Commissioning, use.....	5
4. Parameters, settings .....	7
5. Terminal plan, technical data .....	7
6. De-commissioning, disposal.....	9



The present document is a supplement to the Installation and Operating instructions: Flamcomat, Doc.no.: MC00018/08-2012/en; Flexcon M-K, Doc. no.: MC00019/11-2010/eng and must be used with these basic documents only. The general safety instructions contained therein apply in particular, as does the information on equipment, use and function. In each case the latest version is valid (for information, tel. +49 (0) 2052 887 69).

## 1. Appropriate use.


Electronic function assembly, expansion for an SPCx-lw / hw control unit for the activation of the 0-10V analogue signal for the available vessel capacity and actual pressure input signals to the external pressure unit with pump (Flamcomat) or compressor (M-K).

The declaration of conformity in the basic document is applicable. The usual use is to show and analyse this data in remote control centres for process logging, process evaluation and defining an error-management system. Signal processing units may include: programmable, two-channel display/evaluation unit with limit definition, tendency evaluation, relay switch points, digital/analogue display; data logger...

## 2. Equipment, installation of module




Original equipment: The module is an integral part of the control unit for external pressure (Fig. 1; 3; 8). Supplementary equipment: The packaging contains item 1a (fig. 4), the actions involved in fig. 7 and 8 may be carried out on switching off the power supply only. The extension (item 1b, figs. 2 and 5) is available for the use of control units for 3-phase operation (SPCx-hw) and original equipment with phase monitor. In this case, the socket connector (item 1.1) is the installed signal input (additional function).

1a	SPC module, volume / pressure analogue.	3	Control unit SPCx-lw.
1b	SPC module, volume / pressure analogue, phase monitor.	3.1	Phase monitor
1.1	Socket connector, contour-coded; phase monitor signal input.	4	SPC Terminal
1.2	Version type, back: SPC_ANA_V(...) . (...).	4.1	Sensor button: "Error message display", active on backlighting red on.
1.3	LED green, housing illuminated (functioning).	5	Control unit SPCx.
1.4	LED red, housing illuminated (error).	5.1	Slots 1...4.
1.5	Connector strip	5.2	Breaking point field
2	Control unit SPCx-lw	5.3	Breaking point field opening
2.1	Information, note: Dangerous voltage! To be opened by qualified personnel only. Disconnect from power supply before opening the unit.	5.4	Slot 3
		5.5	Extra-low voltage terminals.



## 3. Commissioning, use

The expansion module in position on the fastened control unit cover, that allows the power supply and control unit to be switched "On" in place, menu [11-3-8] gives access to the version view of the following extension:

Service menu [11] »  [11] » Version information [11-3] »  [11-3] » slot 3 [08.03.11] »  [11-3-8]

If the version number under [11-3-8] is missing, the module is not ready for operation (see page 6 - Internal and external error messages). The initialized module (ready for operation) enables the signal output from Start in the start menu [9-9] (equipment operational). Changes to the configuration that stop the control functions (in the menu navigation, confirming the question 'Stop system?') interrupt the Capacity signal output, pressure analogue.


To maintain the signal output, it is essential that the power supply is available, the control unit is switched on and the equipment sensors are functioning properly. To service the sensors, the requisite factory settings/initial conditions must be restored.

Note: Drawings of components may differ from actual parts supplied.



## Commissioning, use

### Location of data in menu:




Internal messages; LED displays on the module (nos. 1.3 and 1.4);		
Status	Description	measures
Green "Off"	Module not recognised, not available, no access (version number under [11-3-8] not available).	Control unit, power supply; use indicated slot; clean contact surfaces of the connector strip.
Green "On"	Module recognised.	Function available.
Green "flashing"	Data transfer	-
Red "Off"	No errors.	-
Red "On"	Use of module blocked (Licensing of headings).	Use module on one of three previously used control units.
Red "intermittent"	Last action resulted in error.	Carry out positioning under initial conditions (see also: "External error message", 60 module).

External error message; applicable error message after going to message display on terminal if error message shown:		
Display	Description	measures
60 Extension	Last external module action resulted in error (identical to LED red, flashing intermittently; no. 1.4). Important: Error not saved, not contained in menu [11-6] (Error history, analysis).	Acknowledgement deactivates the error message and the flashing red LED. (No consequences if the error is not acknowledged). Check module positioning (module may be removed).

## 4. Parameters, settings

As a result of the practical application, the parameters for evaluation depend on the control unit configuration and the parameter settings. The actual values of an active control unit are specified in the menu [8-1-1] (Pressure, customer access) and [8-2-3] (Capacity, access by qualified personnel). Further information is available from Flamco Support/Flamco Service on demand. Recommended: If the expansion module control unit contains an SD - card, an appropriate configuration file for the situation at hand can be saved to a data carrier. The e-mail sent to Flamco Support / Service and the file attached must be an unambiguous communication.

Parameters, examples of the display of the terminal:



### Explanatory note:

Instances of excess pressure at the unit pressure sensor.

$P_{sv}$  6.0 Maximum possible pressure setting of the safety valve of the system ( $\leq$  nominal pressure of the unit in question).

$P_e$  5.4 Maximum end pressure (upper limit of the working pressure range;  $P_e = P_{sv}$  - closing pressure difference of the safety valve in question).

$P_{A+}$  0.2 Upper working pressure tolerance (hysteresis), pressure drop: 'On'.

$P_A$  2.0 Working pressure, pressure drop, -pressure increase: 'Off'.

$P_{A-}$  0.2 Lower working pressure tolerance (hysteresis), pressure increase: 'On'.

» Working pressure range = 1.8...2.2 bar

$P_+$  0.3 Positive pressure, extra pressure to guarantee excess pressure.

$P_o$  1.5 Calculated display value:  $[P_{A+}] - [P_{A-}] - [P_+]$  (Minimum required excess pressure).

### Explanatory note:

Values assigned to the actual pressures of the capacity sensor.

100 Vessel filled to capacity.

94 Draining value: 'On'.

2 Amount to be subtracted for draining: 'Off' (hysteresis), falling fill level (94-2=92).

3 Sum 1, topping up: 'Off', rising fill level (6+3+3=12; upper water feed value).

3 Sum 2, topping up: 'On', falling fill level (6+3=9).



6 Lower water feed value; Rise in pressure: 'On', falling fill level; [Rise in pressure: 'On'. Sum 2 minus 1, rising fill level (6+3-1=8)].

0 Operation balance value in start menu [9-6...7] (Empty vessel).

Note: Equipment for topping-up and draining may be optional extras.



## 5. Terminal plan, technical data



## 6. De-commissioning, disposal.

Removal of the expansion module from the slot interrupts the signal transmission to the outputs (error no. 60 Expansion module, page 6). If this electronic component is to be disposed of, this must be performed in line with the requirements of the waste-disposal company in question.



# Flamco



**KE KELIT**®  
CLIMATE CONTROL SYSTEMS

KE KELIT NZ Ltd.  
0800 4 KE KELIT  
0800 4 5353548  
climatecontrol@kekelit.co.nz  
www.kekelit.co.nz

Copyright Flamco B.V., Bunschoten, the Netherlands.

Nichts aus dieser Ausgabe darf ohne ausdrückliche Freigabe und mit Angabe der Quelle vervielfältigt oder auf irgendeine andere Weise veröffentlicht werden. Die erwähnten Angaben gelten nur für die Anwendung von Flamco Produkten. Für eine unsachgemäße Nutzung, Anwendung oder Interpretation der technischen Daten übernimmt Flamco B.V. keine Haftung. Technische Änderungen vorbehalten.

Copyright Flamco B.V., Bunschoten, the Netherlands.

No part of this publication may be reproduced or published in any way without explicit permission and mention of the source.

The data listed are solely applicable to Flamco products.

Flamco B.V. shall accept no liability whatsoever for incorrect use, application or interpretation of the technical information.

Flamco B.V. reserves the right to make technical alterations.