

Specification Clause

V950 Ductile Iron Gate Valve Series

V950 Ductile Iron, V951Cast iron





1.0 Product Overview and Technical Details

The valves shall be drawn from the Pegler Commercial Cast Iron gate valves (available from Pegler Yorkshire Group) are intended for the isolation of sections of pipe work and equipment in HVAC applications and general commercial applications. The valves have non rising stems and operated by wheel handles.

1.1 Tube compatibility

Valve Type	Flange Connection Specification		
V950 PN16	Flanges to EN1092-2 PN16		
V951 PN6	Flanges to EN1092-2 PN6		

1.2 Pressure ratings

Pressure and Temperature ratings

Valves must be installed in a piping system whose normal pressure and temperature does not exceed the stated rating of the valve. The maximum allowable pressure in valves as specified in the standards is for non shock conditions. Water hammer and impact should also be avoided.

If system testing will subject the valve to pressures in excess of the working pressure, this should be within the "shell test pressure for the body" to a maximum of 1.5 times the PN rating of the valve and conducted with the valve fully opened.

It may be hazardous to use these valves outside of their specified pressure and temperature limitations and also when not used for the correct application.



Technical Performance Specification

V950

Complies with BS5150 (EN1171) Flanges to EN1092-2 PN16 Non rising stem Size range DN65 to DN300 Gland packing graphite non-asbestos Ductile iron body and bonnet Bronze trim EN1982 CC491K Temperature range -10°C to +120°C

V951

Complies with BS5150 (EN1171)
Flanges to EN1090-2 PN6
Non rising stem
Size range DN65 to DN200
Gland packing graphite non-asbestos.
Cast iron body and bonnet
Bronze trim EN1982 CC491K
Temperature range -10°C to +120°C

2.0 Installation

2.1 Electrical continuity

All metallic pipework should comply with the equipotential bonding requirements of the current edition of the IEE wiring regulations (BS7671:2001). After all plumbing work has been completed continuity checks are to be conducted by a qualified electrician in accordance with the regulations.

2.2 Heat free

The Pegler V950, V951 Series offers Heat free jointing across its whole range with flanged connection technology. These valve connections must not be brazed.

2.3 Insulation

For all Pegler V950,V951 Series valves, it is recommended that you adhere to the insulation requirements as specified by the Water Supply(Water Fittings Regulations 1999, ensuring at all times that access for valve operation is taken into consideration.

2.4 Valve selection

Valves must be properly selected for their intended services conditions. Provided it is installed correctly and receives adequate preventative maintenance it should give years of trouble free service.

They must be compatible with the system design, pressure and temperature requirements and must be suitable for the fluids that they are intended to carry. Interactions between metals in the pipe system must be considered as part of the valve selection.

Gate valves perform best when they are installed in an upright position. The direction of flow is not important. They are fitted when the valve is in the open position.

Gate valves are designed for isolation and should either be fully opened or fully closed and should not be used for regulation or throttling of flow.



2.5 Location/end of line service

To ensure ease of operation, adjustment, maintenance and repair, valve siting should be decided during the system design phase.

Pegler gate valves are not suitable for end-of-line service.

Where gate valves are required for end of line service a blanking flange must be fitted to the downstream end of the valve.

2.6 Pre Installation- Health and Safety

Before starting work on any installation a risk assessment must be made to consider the possibility of operational limits being exceeded and reduction or elimination of ant potential hazards.

- 1. Protective clothing and safety equipment must be utilized as appropriate to the hazard presented by the nature of the process to which the valve is being installed or maintained.
- 2. Before installing or removing a valve the pipeline circulating pumps (when fitted) must be turned off. The pipeline must be depressurised, drained and vented. Valves must be fully opened to ensure release of any pipeline or valve pressure.
- 3. Fitters must be trained in manual and mechanical handling to enable them to safely lift and install Pegler valves.
- 4. The valve selected must be suitable for the required service conditions. The pressure and temperature limitations are indicated on the valve nameplates, body or data plate. They must not be exceeded.
- 5. Valve seats, seals and internal components can be damaged by system debris. Protective devices may need to be fitted and system flushing may be required.
- 6. Any flushing fluid used to clean the pipeline must not cause any damage to the valve and its components.
- 7. Pegler valves must not be misused by lifting them by their hand wheels, levers or valve stems.
- 8. Pegler valves are not suitable for fatigue loading, creep conditions, fire testing, fire hazard environment, corrosive or erosive service, or for carrying fluids containing abrasive solids. There is no allowance for corrosion in the design of these valves. Design for this valve do not allow for decomposition of unstable fluids and must not be used where this could occur.
- 9. Pegler valves are not designed to withstand the effects of fire, wind, earthquakes and traffic.
- 10. All Health and Safety Rules must be followed when installing and maintaining valves.

2.7 Installation - Flanged valves

Unpack the valve.

Check that the valve is correct for its intended use.

Ensure that any flange protectors are removed.

Check that the flow paths are clear and that the threads are clean and free from debris.

Ensure that the valve is fully open during installation.

Flange components have their own design limitations and correct selection and compatibility is vital.

Flange material specification:

Pressure and temperature must not exceed its rating Gasket selection must be in line with the rating of the flange The fluid being handled will affect the gasket selection.

All bolts must be compatible with the mating flange being used.

Pipe and its mating flange should be cleaned and made ready for assembly.

A clean and appropriate gasket should be selected for the flange type being used.

Flat face and raised faces flanges should not be mixed.

Piping should be properly supported with the use of correctly sized hanging or securing brackets.



All pipes need to be aligned correctly to ensure that the valve integrity is maintained, avoiding twisting and distortion of the valves structure and valve damage. As the valve is assembled in the pipeline ensure that the bolts are placed and secured with nuts at hand tightness employing the crossover method of tightening to secure a sound and leak tight joint.

Butterfly valves provide positive shut off in both directions. The disc profile is designed to give sealing properties at minimum torque. Raised seat profile provides a positive flange seal.

Use suitable hangers close to both ends of the valve in order to remove stresses transmitted by the pipe.

3.0 Testing

DN50-DN300 - each products shall be pneumatically tested at 6 bar (90psig) for 5 sec. There shall be no signs of visible leakage from the Body / Bonnet joint, surfaces or seals.

After testing

the valves shall be left fully 'Open'.

Type Testing

These tests shall be carried out at Pegler Limited on a sample basis in accordance with BS6001.

<u>DN50-DN300 PN16</u>	<u>DN65-DN200 PN6</u>
24 bar	9bar
17.6 bar	6.6bar
6 bar	6bar
6 bar	6bar
	24 bar 17.6 bar 6 bar

Valve Type	Max. working Pressure(Bar)	Temperature at Max. working Pressure	Max. Working Temperature	Max. working pressure at Max. temperature(bar)
Flanges to PN16	16	up to 120°C	Up to 120°C	16
Flanges to PN6	6	up to 100°C	up to 120°C	6

Certification

Not applicable.

Operation/ Commissioning

Pegler V950, V951 series valves: To open – an anti clockwise rotation of the hand wheel will open the valve. When it will go no further then rotate the hand wheel clockwise a - turn. To close - a clockwise turn of the hand wheel. Closure will be confirmed when the handle can be turned no further.



3.1 Additives

It is strongly recommended to consult a commissioning engineer in conjunction with the manufacturer prior to their use.



3.2 Warranty

Products are subject to a 5 year guarantee that is between Pegler Yorkshire and the final purchaser of the product.

The guarantee is subject to proof of purchase being supplied.

This guarantee does not affect any statutory rights the consumer may have in law.

The guarantee covers manufacturing or material defects and does not cover parts subject to normal wear and tear.

This product range has been designed for the use in commercial applications and therefore the guarantee is subject to the product being properly selected for their intended service conditions. The guarantee is not applicable where the product is fitted contrary to the conditions in the fitting instructions.

This is reinforced where valves are covered by the European Pressure Equipment Directive (PED97/23/EC) where Installation, Operating and Maintenance Instructions are supplied with each product and/or carton.

Provided it is installed correctly and receives adequate preventative maintenance it should give years of trouble -free service.

Abusive behaviour and accidental damage to the product are not covered by this guarantee. The extent of this liability is limited to the cost of the replacement of the defective item and not to fitting or consequential damages.

4.0 Storage

Valves should be stored off the ground in a clean, dry, indoor area. Where desiccant bags are included these should be changed after a period of six months.

Pegler valves are supplied in appropriate packaging to give adequate protection from damage. Cast iron and steel valves may also have end protection caps.

When Pegler valves are fitted to pressure equipment or assemblies, suitable protective devices may be required.

5.0 Contact details

For further details please contact our technical department: 0800 156 0050

Pegler Yorkshire Group Limited, St. Catherine's Avenue, Doncaster, South Yorkshire DN4 8DF

tech.helpline@pegleryorkshire.co.uk www.pegleryorkshire.co.uk

