

Product Data Sheet

Pressure Gauges

The pressure in the installation is indicated by the pressure gauge.



Type	Connection	Pressure range [bar]	Marking [bar]	Shut-off valve	###	Order Code
Pr. gauge Ø 40 ax. for Prescomano	$\frac{1}{4}$ ax.	0 - 4	1.5 - 3.0	no	1	27264
Pr. gauge Ø 40 ax. for Prescomano	DN 10 ($\frac{1}{8}$) ax.	0 - 4	1.5 - 2.5	no	1	27260
Pr. gauge Ø 63 rad. / 4.0b.	$\frac{1}{4}$ rad.	0 - 4	1.5 - 3.0	no	1	27205
Pr. gauge Ø 63 rad. / 3.0b.	$\frac{3}{8}$ rad.	0 - 4	1.5 - 3.0	no	1	27200
Pr. gauge Ø 63 rad. / 1.5 - 4.0b.	$\frac{3}{8}$ rad.	0 - 4	1.5 - 4.0	no	1	27203
Pr. gauge Ø 63 ax. / 6.0 b.	$\frac{1}{4}$ ax.	0 - 6	2.5 - 6.0	no	1	27211
Pr. gauge Ø 63 rad. / 2.0 - 4.0b.	$\frac{3}{8}$ rad.	0 - 4	2.0 - 4.0	no	1	27208
Pr. gauge Ø 63 rad. / 2.5 - 4.0b.	$\frac{3}{8}$ rad.	0 - 4	2.5 - 4.0	no	1	27204
Pr. gauge Ø 63 rad. / 3.0 - 4.0b.	$\frac{3}{8}$ rad.	0 - 4	3.0 - 4.0	no	1	27202
Pr. gauge Ø 63 rad. / 2.5b.	$\frac{3}{8}$ rad.	0 - 4	1.5 - 2.5	no	1	27201
Pr. gauge Ø 63 ax. / 1.5 - 4.0b.	$\frac{3}{8}$ ax.	0 - 4	1.5 - 4.0	no	1	27213
Pr. gauge Ø 63 ax. / 3.0b.	$\frac{1}{4}$ ax.	0 - 4	1.5 - 3.0	no	1	27210
Pr. gauge Ø 80 rad. / 3.0b.	$\frac{1}{4}$ rad.	0 - 4	1.5 - 3.0	$\frac{1}{4}" \times \frac{1}{2}"$	1	27220
Pr. gauge Ø 80 ax. / 3.0b.	$\frac{1}{4}$ ax.	0 - 4	1.5 - 3.0	$\frac{1}{4}" \times \frac{1}{2}"$	1	27230
Pr. gauge Ø 80 rad. / 3.0b.	$\frac{1}{2}$ rad.	0 - 4	1.5 - 3.0	no	1	27222
Pr. gauge Ø 100 0 - 10 bar rad.	$\frac{3}{8}"$ rad.	0 - 10	6.0	no	1	27243
Manometer Ø 50 exc.	$\frac{1}{8}"$ ax. not central	0 - 4	1.5 - 3.0	no	1	27267

Type	Connection	Pressure range [bar]	Marking [bar]	Shut-off valve	###	Order Code
Manometer Ø 50 exc.	1/8" ax. not central	0 - 12	variable	no	1	27263
Manometer 40 mm 1 mtr capillair	1/4" ax. cap. conn.	0 - 6	Flexibel capillair 2mm à 1 mtr	no	1	27269



Find more information online:

[Manuals](#)

[Extra documentation](#)